


INSTALLATION, OPERATION AND MAINTENANCE HAYWARD ELECTRIC ACTUATED BALL VALVE

**MODEL: EATB1050STE
EATB1075STE
EATB1100STE
EATB1150STE
EATB1200STE**

**The Hayward Electric Actuator is premounted
to a valve assembly and factory tested.**

- 1. DISCONNECT THE POWER SUPPLY!**
- 2. COMPLIANCE TO LOCAL BUILDING/ELECTRICAL CODE
SHOULD BE MAINTAINED.**

**The electrical connections to the actuator must be properly connected
with the installation schematic below. The wire leads must be properly
sized and wire connected as required by code.**



Dotted lines indicate wiring by purchaser.